

Juniper SRX 日本語マニュアル

Security Policy の CLI 設定

JUNIPER
NETWORKS

Driven by
Experience™

はじめに

- ◆ 本マニュアルは、Security Policy の CLI 設定について説明します
- ◆ 手順内容は SRX300 、Junos 21.2R3-S2 にて確認を実施しております
- ◆ 実際の設定内容やパラメータは導入する環境や構成によって異なります
各種設定内容の詳細は下記リンクよりご確認ください

<https://www.juniper.net/documentation/>

- ◆ 他にも多数の SRX 日本語マニュアルを「ソリューション & テクニカル情報サイト」に掲載しております
<https://www.juniper.net/jp/ja/local/solution-technical-information/security.html>

2022 年 8 月

Security Policy

以下の設定を行う場合のコマンド例となります

設定するセキュリティポリシーの内容

- ・ 送信元ゾーン trust
- ・ 宛先ゾーン trust
- ・ ポリシー名 policy1
- ・ 送信元アドレス 全て許可
- ・ 宛先アドレス 全て許可
- ・ アプリケーション 全て許可

Security Policy

1. 全ての送信元を設定します

```
user@srx# set security policies from-zone trust to-zone trust policy policy1 match source-address any
```

2. 全ての宛先を設定します

```
user@srx# set security policies from-zone trust to-zone trust policy policy1 match destination-address any
```

3. 全てのアプリケーションを設定します

```
user@srx# set security policies from-zone trust to-zone trust policy policy1 match application any
```

4. 条件に一致した通信を許可します

```
user@srx# set security policies from-zone trust to-zone trust policy policy1 then permit
```

Security Policy

設定の確認

```
user@srx# show
security {
  policies {
    from-zone trust to-zone trust {
      policy policy1 {
        match {
          source-address any;
          destination-address any;
          application any;
        }
        then {
          permit;
        }
      }
    }
  }
}
```




Thank you

JUNIPER
NETWORKS®

Driven by
Experience™